


Installing edgemounts on walls

- Use your panel as the template to position panels on walls.
- Ensure that the fixings you use to secure G Parts are suited to the type of wall they are being attached to e.g. when securing to wood use 8 gauge counter sunk head wood screws. When securing to plaster board, concrete, block etc. obtain wall anchors specifically designed for use with the wall material from your hardware store or specialist supplier.
- Ensure that your G Parts are secured strongly enough to hold the entire loading on the G+L Parts.


INSTALLATION

without border




INSTALLATION

with border





Installing edgemounts on panels




	Bolt Dimensions			Recommended Fastening System			
	Button Head Bolt Thread Diameter	Thread Length	Overall Length	4			is 4
	M4	9mm	12mm				N.
	.157"	.354"	.472"	M4 Bolt	M4 x Ø11 M4 x Ø8	M4	
Add nanel thickness to helt lengths above					Wacher Lock Wacher	Hay Nut	"

The intellectual property in this drawing is the property of Pizazz International Limited 40 William Pickering Drive, Auckland, New Zealand. Copyright © Pizazz International Limited 2011.Unauthorised use prohibited.



Mounting edgemounts back to back



	Bolt Dimensions			Recommended Fastening System			
	Button Head Bolt Thread Diameter	Thread Length	Overall Length	4			is 4
	M4	9mm	12mm				N.
	.157"	.354"	.472"	M4 Bolt	M4 x Ø11 M4 x Ø8	M4	
Add nanel thickness to helt lengths above					Wacher Lock Wacher	Hay Nut	"

The intellectual property in this drawing is the property of Pizazz International Limited 40 William Pickering Drive, Auckland, New Zealand. Copyright © Pizazz International Limited 2011. Unauthorised use prohibited.